

Behind The Head Headset Conversion Instructions

1. Remove the Over The Head Headband
Use a standard torx T10 Screw Driver remove 4 screws
2. Install the Behind The Head Headband (Fig. 1)
Use a standard torx T10 Screw Driver remove 4 screws
3. Tape crossover wire to headband (Fig. 2-3)
4. Install Nylon Velcro Wrap (Fig. 3)
5. Install Nylon Headband Strap (Fig. 4)

